

GOC TECHNOLOGIES

623 Kakoi Street SPC 1
Honolulu, HI 96819
PH: 808 839-1300

COMPACTOR P/M INSPECTION REPORT

Property Name		Date	
Service Type	<input type="checkbox"/> Monthly <input type="checkbox"/> Qtrly <input type="checkbox"/> Annual	Service Rep	

Safety & Fluid Check	OK	Worn/Def	Comments/Parts Needed/Type of Repair
1. Retract compaction cylinders, check fluid level	<input type="checkbox"/>	<input type="checkbox"/>	
2. Power cord, conduit, plug, socket condition, etc.	<input type="checkbox"/>	<input type="checkbox"/>	
3. Key on/off, start, and emergency stop switches	<input type="checkbox"/>	<input type="checkbox"/>	
4. Reverse/forward, up/down selector switches	<input type="checkbox"/>	<input type="checkbox"/>	
5. Door enclosure safety switch, 80%-100% full lights, Electrical controls & Circuits (check)	<input type="checkbox"/>	<input type="checkbox"/>	

Electrical Controls and Circuits (check):	OK	Worn/Def	Comments/Parts Needed/Type of Repair
6. PLC control, transformer, starter control, overload	<input type="checkbox"/>	<input type="checkbox"/>	
7. Wires, connectors, fuses @ these points	<input type="checkbox"/>	<input type="checkbox"/>	
8. Contact blocks, wires, connections, and condition	<input type="checkbox"/>	<input type="checkbox"/>	
9. All selector switch – contact blocks, connectors, wires, etc	<input type="checkbox"/>	<input type="checkbox"/>	
10. Relays, circuit breakers, fuses, sockets, etc.	<input type="checkbox"/>	<input type="checkbox"/>	
11. Photo eyes, magnetic contact switches, limit switch activation and securement	<input type="checkbox"/>	<input type="checkbox"/>	
12. All wiring harness, cables, connection between power Unit and remote box	<input type="checkbox"/>	<input type="checkbox"/>	
13. Motor activation wiring	<input type="checkbox"/>	<input type="checkbox"/>	
14. Ozone ballast, lamp fuses, cover, insulation, clean	<input type="checkbox"/>	<input type="checkbox"/>	
15. Sonozaire hook up and operation	<input type="checkbox"/>	<input type="checkbox"/>	
16. Cleanliness of sections just inspected	<input type="checkbox"/>	<input type="checkbox"/>	

Hydraulic Systems (check)	OK	Worn/Def	Comments/Parts Needed/Type of Repair
17. Power unit motor, pump, circulation, psi	<input type="checkbox"/>	<input type="checkbox"/>	
18. Pressure switch, relief valve, direction valve condition and activation	<input type="checkbox"/>	<input type="checkbox"/>	
19. Sight glass, pressure gauge, condition, etc.	<input type="checkbox"/>	<input type="checkbox"/>	
20. Fittings, hoses, tube lines, for leaks, etc.	<input type="checkbox"/>	<input type="checkbox"/>	
21. Quick disconnects and clean	<input type="checkbox"/>	<input type="checkbox"/>	
22. Reservoir breathe cap, cover plate seal, bolts, welds	<input type="checkbox"/>	<input type="checkbox"/>	
23. Compaction cylinder gland, rod, condition, etc.	<input type="checkbox"/>	<input type="checkbox"/>	
24. Cart dumper cylinder, gland, rod condition, etc.	<input type="checkbox"/>	<input type="checkbox"/>	
25. Hydraulic hose, fittings @ these sections	<input type="checkbox"/>	<input type="checkbox"/>	
26. Clean out cylinder compartment.	<input type="checkbox"/>	<input type="checkbox"/>	
27. Clean power unit section	<input type="checkbox"/>	<input type="checkbox"/>	
28. Cycle unit check all functions	<input type="checkbox"/>	<input type="checkbox"/>	
29. Cycle unit record psi	<input type="checkbox"/>	<input type="checkbox"/>	

GOC TECHNOLOGIES

623 Kakoi Street SPC 1
Honolulu, HI 96819
PH: 808 839-1300

COMPACTOR P/M INSPECTION REPORT

Property Name			Date	
----------------------	--	--	-------------	--

Mechanical (check)	OK	Worn/Def	Comments/Parts Needed/Type of Repair
30. Channel, roller wheels, stops (grease)	<input type="checkbox"/>	<input type="checkbox"/>	
31. Container x beams, supports, welds, structure	<input type="checkbox"/>	<input type="checkbox"/>	
32. Rear door, hinges, turn buckle ratchet (grease)	<input type="checkbox"/>	<input type="checkbox"/>	
33. Rear door seal and alignment	<input type="checkbox"/>	<input type="checkbox"/>	
34. Dog house enclosure/hopper chute condition	<input type="checkbox"/>	<input type="checkbox"/>	
35. (P200) Loading door, guide rails, chain and pulley	<input type="checkbox"/>	<input type="checkbox"/>	
36. (P200) Counter weight channel door pin	<input type="checkbox"/>	<input type="checkbox"/>	
37. Cart dumper, rails, joints, pins, bolts (grease)	<input type="checkbox"/>	<input type="checkbox"/>	
38. Cart dumper cylinder pins, rod eye condition (grease)	<input type="checkbox"/>	<input type="checkbox"/>	
39. Compaction cylinder rod eye, mounts, pins (grease)	<input type="checkbox"/>	<input type="checkbox"/>	
40. Compactor structural, xbeams, rails, wear pads	<input type="checkbox"/>	<input type="checkbox"/>	
41. Platen, top cover plate, xbreaks, chamber conditions	<input type="checkbox"/>	<input type="checkbox"/>	
42. Turnbuckle ratchet, hook,, mounting plate, pin (grease)	<input type="checkbox"/>	<input type="checkbox"/>	
43. Limit switch activation, mounting, adjustment	<input type="checkbox"/>	<input type="checkbox"/>	
44. (P200) Platen, platen x beam, wear pads, mounts	<input type="checkbox"/>	<input type="checkbox"/>	
45. (P200) Pivot arm, base, lifting bar, pins, etc.	<input type="checkbox"/>	<input type="checkbox"/>	
46. Bin container, frame assembly, swivel caster, bolts, (grease)	<input type="checkbox"/>	<input type="checkbox"/>	

Annual Service: to include items (1 - 46)	OK	Worn/Def	Comments/Parts Needed/Type of Repair
47. Drain reservoir, clean internally and inspect	<input type="checkbox"/>	<input type="checkbox"/>	
48. Change filter, suction screen, and gasket seal, securing all fittings, suction lines and mounts	<input type="checkbox"/>	<input type="checkbox"/>	
49. Inspect pump, motor coupling	<input type="checkbox"/>	<input type="checkbox"/>	
50. Inspect breather cap condition cleaning magnet plug	<input type="checkbox"/>	<input type="checkbox"/>	
51. Add hydraulic oil, record gallons used	<input type="checkbox"/>	<input type="checkbox"/>	
52. Cycle machine check all functions	<input type="checkbox"/>	<input type="checkbox"/>	